

Exceptionally solid engineered floors

# **TECHNICAL DATA SHEET**

# Oak Basalt, burnt brushed and oiled



## **PRODUCT DETAILS**

Product range	BURNT OAK, with a highly-textured surface to give a weathered appearance
Available formats	Boards, herringbone, chevron
Sizes	Board widths: 145mm / 185mm / 225mm / 245mm / 285mm / 300mm
	Board lengths: random between 1.5m and 2.5m (285mm and wider are produced in longer lengths)
	Herringbone and chevron parquet: 65 x 325mm / 85 x 425mm / 105 x 525mm / 145 x 580mm / 145 x 725mm / 185 x 925mm
Depth	20mm
Construction	Engineered with birch plywood base
Finish	Burnt, heavily brushed and oiled with hardwax oil
Profile	Tongue and groove
Edge profile	Bevelled edge on long sides
Wear layer	6mm

#### WARRANTY AND INSTALLATION

Manufacturer's warranty: 5 years, subject to terms and conditions. Note there is no warranty on the finish as we have no control over usage and aftercare. All our floors must be installed by a competent installer onto a firm, level (flat), clean and dry substrate. The site must be heated if necessary and water tight with all glazing fitted. Wet works such as plastering and tiling must be completed prior to installation.

### **GRADES**

Premier	Occasional, small knots up to 15mm
Rustic A	Knots up to 40mm, including filled knots, sapwood up to 10mm
Rustic	Frequent knots up to max. 80mm, including filled knots and cracks up to 400mm, sapwood up to 25mm, centre core

Premier and Rustic A grades are available in widths up to 245mm

### **TECHNICAL CRITERIA**

Origin	Europe
Certification	PEFC, FSC on request
Formaldehyde emission	E1
Thermal conductivity	0.17 W/mk

## **MAINTENANCE**

Initial care & re-oiling	Do not clean the floor with water in the first 4
	weeks after installation
	Under no circumstances should any
	chemicals/white spirit/detergent cleaners be used as
	these will remove the protective oiled finish
	We recommend a final coat of oil after installation
	Re-oil every 2-5 years depending on the volume of
	traffic. High usage areas may require annual re-oiling
	Use Osmo Polyx Hardwax Oil Clear matt
	Prior to re-oiling wash the floor with Woca Wood
	Cleaner and leave to dry for 8 hours
General cleaning	Use Osmo Wash and Care soap for regular cleaning
	and Osmo Liquid Wax Cleaner Spray for stubborn
	stains
	Do not rub individual spots as you risk removing
	the layers of coloured oil and revealing the black
	surface of the wood. Carefully clean off marks with
	Osmo Liquid Wax Cleaner Spray

## **INSTALLATION METHODS**

Fixed installation	Fully bonded to the subfloor
Floating installation	Not advisable
Over underfloor	This floor is compatible with UFH. Floors must be
heating	fully bonded to the substrate
	The temperature of the floor surface must not
	exceed 27 degrees. Floor sensors must be installed to
	monitor the maximum temperature

Waxed Floors, 92 Battersea Rise, SW11 1EJ, London T. +44 20 7738 1620 F. +44 20 7738 1630 sales@waxedfloors.co.uk www.waxedfloors.co.uk

The company reserves the right to change this specification at any time without prior notice to third parties. The image is intended as a guide only and should not be regarded as absolutely accurate.